

NiftyKEYZ firmware updates

To benefit from the latest features and optimisations we strongly recommend updating your NiftyKEYZ before use. You can download the necessary files from our NiftyKEYZ web page:

<https://www.cre8audio.com/niftykeyz>

Firmware updating is the same easy process on a PC and Mac and requires no drivers. Please follow the 5 steps below, watch the end of our [video manual](#) for a demonstration of the firmware update on both PC and MAC.

How to update

- Connect NiftyKEYZ to your computer with a USB cable type A male to USB type B male cable.
- Power On NiftyKEYZ
- Double click the updater icon
- Click the load button and browse to the .DFU (device firmware update) file.
- Click update and you're done!

Mac Updater

MultiChip Updater V1.0.0

Firmware

VID: 0x1acc PID: 0x1a68/0x1a59

New version: V0.1.0.3 Installed version: 1.02

1/1

PC Updater

MultiChip Updater

Firmware

VID: 1acc PID: 1a59/1a68

New version: V0.1.0.3 Installed version: V0.1.0.2